

This document describes the initial setup of an Aruba user-centric network that consists of an Aruba controller and Aruba Access Points (APs). The installation consists of the following steps:

1. Launch the WebUI or Console Setup Wizard to configure the controller.
2. Connect the controller to the wired network.
3. Configure the controller to allow APs, when installed and powered on, to be able to locate and connect to the controller. If you are configuring mesh, define the mesh cluster profile, mesh radio profile, before installing APs in a mesh networking environment.
4. Install and connect your APs to the network.

Before you begin, read the *ArubaOS End User License Agreement* and review the contents of your controller shipment to ensure that you have received the following:

- Aruba controller with appropriate power cord and accessories
- The *ArubaOS Quick Start Guide*.
- The *ArubaOS End User License Agreement*

Install the Controller

The WebUI Startup Wizard allows you to configure access to the controller, install software licenses, and configure wireless local area networks (WLANs) for internal or guest users. The Startup Wizard is available the first time you connect to and log into the controller or whenever the controller is reset to its factory default configuration. The serial console setup dialog allows you to configure basic controller settings through a serial port connection to the controller. After you complete the Startup Wizard or serial console setup procedure, the controller reboots using the new configuration information you entered.

Do not connect the controller to your network when running the Setup Wizard or serial console setup dialog. The factory-default controller boots up with a default IP address and both DHCP server and spanning tree functions enabled. Once you have completed setup and rebooted the controller, you can use the controller CLI or WebUI to complete its configuration before connecting the controller to your network.

Initial Setup Using the WebUI Setup Wizard

The following browsers are officially supported for use with the ArubaOS 6.3 Setup wizard and WebUI:

- Microsoft Internet Explorer
- Mozilla Firefox on Windows XP, Windows Vista, Windows 7, and MacOS
- Apple Safari on MacOS

You can launch the setup wizard using any PC or workstation that can run a supported Web browser. The PC or workstation must either be configured to obtain its IP address using DHCP, or configured to have a static IP address on the 172.16.0.0/24 subnetwork. The default IP address of the controller is 172.16.0.254. Connect a PC or workstation to a line port on the controller, then enter this IP address into a supported Web browser to launch the Setup Wizard.

To run the Setup Wizard:

1. Determine values for the required configuration settings described in [Table 1](#).
2. Make sure that the controller is not connected to any device on your network.

3. Boot up the controller.
4. Connect your PC or workstation to a line port on the controller.
5. On your PC or workstation, open a Web browser and connect to <https://172.16.0.254>.
6. The controller contains a default server certificate to validate the device on the network. At the Security Alert, click **Yes** to proceed with the Setup Wizard.



The default certificate installed in the controller does not guarantee security in production networks. Aruba strongly recommends that you replace the default certificate with a custom certificate issued for your site or domain by a trusted Certificate Authority. See the *ArubaOS User Guide* for more information about certificates.

7. The initial window of the Mobility Controller Setup Wizard asks you to select one of the following deployment modes. Select **Standalone**, **Master** or **Local**, then click **Continue**.
 - **Standalone**: This is the only controller on the network.
 - **Master**: This controller will manage other controllers on the network.
 - **Local**: This controller will be managed by a master controller.
8. If you selected **Standalone** or **Master** in the step above, you will be prompted to select the **Campus WLAN** deployment mode. The **Remote Access Points** deployment mode allows you to configure additional settings specific to remote APs.
9. Enter the information described in [Table 1](#), and, if desired, the optional configuration information described in "[Optional Information](#)" on [page 3](#).

Table 1 Required Information for the Setup Wizard

Requirement	Description
System Name	A user-defined name by which the controller will be referenced. You can specify a name of up to 63 characters.
Country Code	The country in which the controller will operate. The country code determines the 802.11 wireless transmission spectrum. You cannot change the country code for controllers designated for certain countries, such as the U.S. or Israel. Improper country code assignment can disrupt wireless transmissions. Most countries impose penalties and sanctions for operators of wireless networks with devices set to improper country codes.
Admin Password	Password of up to 32 characters for the admin user to log in to the controller.
Enable Mode Password	Password of up to 15 characters for the admin user to access the Enable mode in the CLI.
Date and Time	You can either manually set the date, time, and GMT time zone or specify the IP address of an NTP server from which the controller will obtain its date and time settings.
Connectivity Settings	Enter the controller IP address and default gateway. The gateway is usually the IP address of the interface on the upstream switch or router to which you will connect the controller. The default gateway and the VLAN 1 IP address need to be in the same network.
Authentication Settings	<ul style="list-style-type: none"> ● If you are configuring a master or local controller that uses pre-shared key authentication, enter the pre-shared key. ● If you are configuring a master controller to use certificate authentication, enter the MAC addresses of the local controllers. ● If you are configuring a local controller to use certificate authentication, enter the MAC address of the master controller.

Optional Information

The Setup Wizard also allows you to:

- Create virtual local area networks (VLANs) into which wireless users are placed after authentication.
- Modify default port settings.
- Enable the Uplink firewall, and configure the following Management and Aruba interface types.
 - Management Interfaces: SSH, HTTPS, SNMP and DHCP.
 - Aruba Interfaces: RAP, VIA, VIA Mac and Site-to-Site VPN
- Install licenses for ArubaOS software modules.
- Configure internal and guest WLANs.
- Specify IP address pools to define the inner IP addresses assigned to VPN clients and access points connecting to a local controller, or to a standalone or master controller with remote APs.

If you plan on adding controller licenses or configuring additional VLANs, WLANs, or port settings on your controller, make a note of the desired licenses or settings before you launch the Setup wizard.



The optional configuration settings described in the section above cannot be configured when running initial setup on a serial port connection.

Initial Setup on a Serial Port Connection

The serial port is located on the front panel of the controller. You can start the Initial Setup dialog when you connect a terminal, PC or workstation running a terminal emulation program to the serial port on the controller.

The serial port connection only allows you to configure the basic configuration required to connect the controller to the network. The recommended browser-based Setup Wizard allows you to also install software licenses and configure internal and guest WLANs (see [“Initial Setup Using the WebUI Setup Wizard” on page 1](#)). If you use the Initial Setup dialog to configure the controller, the browser-based Setup Wizard will not be available unless you reset the controller to its factory default configuration.

To run the Initial Setup dialog from a serial connection:

1. Configure your terminal or terminal emulation program to use the following communication settings:

Table 2 *Terminal Communication Settings*

Baud Rate	Data Bits	Parity	Stop Bits	Flow Control
9600	8	None	1	None

2. Connect your terminal or PC/workstation to the serial port on the controller using an RS-232 serial cable. All accessory kits shipped with Aruba controllers contain an RJ-45 cable and DB-9 to RJ-45 adapter. You may need to provide a USB adapter to connect the serial cable to your PC.
3. Boot up the Aruba controller. After the controller has booted up, you should see a screen similar to the following:

Figure 1 Initial Setup for Serial Port Connection

```
***** Welcome to the Aruba3600 setup dialog *****
This dialog will help you to set the basic configuration for the switch.
These settings, except for the Country Code, can later be changed from the
Command Line Interface or Graphical User Interface.
```

```
Commands: <Enter> Submit input or use [default value], <ctrl-I> Help
<ctrl-B> Back, <ctrl-F> Forward, <ctrl-A> Line begin, <ctrl-E> Line end
<ctrl-D> Delete, <BackSpace> Delete back, <ctrl-K> Delete to end of line
<ctrl-P> Previous question <ctrl-X> Restart beginning
```

- The Serial Port Configuration Dialog displays the configuration prompts described in Table 3. The prompts may vary, depending upon the switch role you choose. Enter the required information at each prompt, then press **Enter** to continue to the next question.

Table 3 Serial Console Configuration Dialog

Console Prompt	Description
Enter System Name	Enter a name for the controller, or press Enter to use the default system name. You can specify a name of up to 63 characters.
Enter VLAN 1 interface IP address	The controller takes its IP address from VLAN 1 and uses this IP address to communicate with other controllers and with APs. Enter the VLAN 1 interface IP address, or press Enter without specifying an IP address to use the default address 172.16.0.254.
Enter VLAN 1 interface subnet mask	Enter the VLAN 1 interface IP subnet mask, or press Enter without specifying an IP address to use the default address 255.255.255.0.
Enter IP Default gateway	This is usually the IP address of the interface on the upstream switch or router to which you will connect the controller. The default gateway and the VLAN 1 IP address need to be in the same network. To continue without specifying an IP gateway, press Enter .
Enter Switch Role, (master local standalone)	Specify one of the following switch roles: <ul style="list-style-type: none"> Master: This controller manages other controllers on the network. You are prompted to specify the type of authentication to be used by the master controller. If you are configuring a master controller that uses pre-shared key authentication to communicate with local controllers, enter the pre-shared key. If you are configuring a master controller to use certificate authentication, specify the MAC addresses of the local controllers. Local: This controller will be managed by a master controller. You are prompted to specify the type of authentication to be used by the controller. If you are configuring a local controller to use pre-shared key authentication to communicate with the master controller, enter the IP address of the master controller and the pre-shared key. If you are configuring a local controller to use certificate authentication, specify the MAC addresses of the master controller. Standalone: This is the only controller on your network.
(For US controllers only) This controller is restricted to Country code US for United States, please confirm (yes no)	If your controller has a country code that restricts its usage, enter yes to confirm this code.
Enter Time Zone	Enter the time zone for the controller, or press Enter to select the default time zone.
Enter Time in UTC	Enter the current time in UTC format, or press Enter to select the default time.
Enter Date (MM/DD/YYYY)	Enter the current date, or press Enter to select the default date.

Table 3 Serial Console Configuration Dialog (Continued)

Console Prompt	Description
Enter Password for admin login (up to 32 chars)	Enter a password to allow the admin user to login to the controller WebUI, CLI and console interfaces. This password can be up to 32 alphanumeric characters long.
Enter Password for enable mode (up to 15 chars)	Enter a password for the admin user to access Enable mode in the controller WebUI, CLI and console interfaces. This password can be up to 15 alphanumeric characters.
Do you wish to shutdown all the ports (yes no)? [no]	Enter yes to shut down all ethernet ports on the controller, or press Enter to allow all ports to remain active.

5. At the end of the Initial Setup, you are asked to review and confirm your configuration changes. Enter **y** to accept the changes. The controller reboots.



If you want to complete optional configuration options (e.g. disabling spanning tree or installing software licenses) before connecting the controller to the network, refer to the *ArubaOS User Guide* for additional information on controller configuration.

Connect the Controller to the Wired Network

Once controller setup is complete, connect a port on the controller to the appropriately-configured port on a Layer-2 switch or router. Make sure that you have the correct cables and that the port LEDs indicate proper connections. Refer to the Installation Guide for your Aruba controller for port LED and cable descriptions.

Configure the Controller to Support APs

Before you install APs in a network environment, you must ensure that the APs will be able to locate and connect to the controller when powered on. Specifically, you need to ensure the following:

- When connected to the network, each AP is assigned a valid IP address
- APs are able to locate the controller

Each Aruba AP requires a unique IP address on a subnetwork that has connectivity to a controller. Aruba recommends using the Dynamic Host Configuration Protocol (DHCP) to provide IP addresses for APs; the DHCP server can be an existing network server or an Aruba controller configured as a DHCP server.

If an AP is on the same subnetwork as the master controller, you can configure the controller as a DHCP server to assign an IP address to the AP. The controller must be the only DHCP server for this subnetwork.

Enable DHCP Server Capability

Use the following procedure to use the controller WebUI to enable DHCP server capability.

1. Enter the IP address of the controller in the URL of a browser window to access the controller WebUI.
2. At the WebUI login page, enter the **admin** user name and the password you entered during the Initial Setup.
3. Navigate to the **Configuration > Network > IP > DHCP Server** page.
4. Select the **Enable DHCP Server** checkbox.
5. In the **Pool Configuration** section, click **Add**.
6. Enter information about the subnetwork for which IP addresses are to be assigned. Click **Done**.
7. If there are addresses that should not be assigned in the subnetwork:
 - a. Click **Add** in the **Excluded Address Range** section.
 - b. Enter the address range in the **Add Excluded Address** section.
 - c. Click **Done**.
8. Click **Save Configuration** at the top of the page to save the configuration to the controller's flash memory.

Controller Discovery

An Aruba AP can discover the IP address of the controller in one of several ways. The Aruba Discovery Protocol (ADP) is enabled by default on all Aruba APs and controllers. If all APs and controllers are connected to the same Layer-2 network, APs will use ADP to discover their controllers. If the devices are on different networks, you must configure the AP to use a Layer-3 compatible discovery mechanism such as DNS, DHCP, or IGMP forwarding after installing the AP on the network. For details, refer to the *ArubaOS User Guide*.

With ADP, APs send out periodic multicast and broadcast queries to locate the master controller. If the APs are in the same broadcast domain as the master controller, the controller automatically responds to the APs' queries with its IP address. If the APs are not in the same broadcast domain as the master controller, you need to enable multicast on the network. If multicast is not an option, then the APs can be configured to use DNS or DHCP based provisioning to contact the controller.

Plan for a Mesh Network Environment



The information in this section applies only if you are configuring and deploying APs in a mesh networking environment. If you are not, proceed to ["Install the APs" on page 7](#).

Before you install APs in a mesh networking environment, you must do the following:

- Define and configure the mesh cluster profile and mesh radio profile before configuring an AP to operate as a mesh node. An AP configured for mesh is also known as a mesh node.
- Provision one of the following mesh roles on the AP:
 - Mesh portal: The gateway between the wireless mesh network and the enterprise wired LAN.
 - Mesh point: APs that can provide traditional Aruba WLAN services (such as client connectivity, intrusion detection system (IDS) capabilities, user roles association, LAN-to-LAN bridging, and Quality of Service (QoS) for LAN-to-mesh communication) to clients on one radio and perform mesh backhaul/network connectivity on the other radio. Mesh points provides LAN-to-LAN bridging through their Ethernet interfaces. It can now provide backhaul and access BSSIDs on the same radio.

For detailed provisioning guidelines, caveats, and instructions, see the "Secure Enterprise Mesh" chapter in the *ArubaOS User Guide*.

Install the APs


Refer to the AP placement map generated by RF Plan to identify the locations in which to physically install your APs. You can either connect the AP directly to a port on the controller, or connect the AP to another switch or router that has Layer-2 or Layer-3 connectivity to the controller. If the Ethernet port on the controller is an 802.3af Power over Ethernet (PoE) port, the AP automatically uses it to power up. If a PoE port is not available, contact your Aruba vendor to obtain an AC adapter for the AP.

Once an AP is connected to the network and powered up, it will automatically attempt to locate the controller. You can view a list of all APs connected to the controller by accessing the **Configuration > Wireless > AP Installation** page in the controller WebUI. An AP installed on the network advertises its default SSID. Wireless users can connect to this SSID, but will not have access to the network until you configure authentication policies and user roles for your wireless users. For complete details on authentication policies and user roles, refer to the *ArubaOS User Guide*.

Contacting Support

Main Site	arubanetworks.com
Support Site	support.arubanetworks.com
Airheads Social Forums and Knowledge Base	community.arubanetworks.com
North American Telephone	1-800-943-4526 (Toll Free) 1-408-754-1200
International Telephones	http://www.arubanetworks.com/support-services/support-program/contact-support
Software Licensing Site	licensing.arubanetworks.com
End of Support information	http://www.arubanetworks.com/support-services/end-of-life-products/end-of-life-policy/
Wireless Security Incident Response Team (WSIRT)	http://www.arubanetworks.com/support-services/security-bulletins/
Support Email Addresses	
Americas and APAC	support@arubanetworks.com
EMEA	emea_support@arubanetworks.com
WSIRT Email Please email details of any security problem found in an Aruba product.	wsirt@arubanetworks.com

Copyright

© 2013 Aruba Networks, Inc. Aruba Networks trademarks include  Airwave, Aruba Networks®, Aruba Wireless Networks®, the registered Aruba the Mobile Edge Company logo, Aruba Mobility Management System®, Mobile Edge Architecture®, People Move. Networks Must Follow®, RFProtect®, Green Island®. All rights reserved. All other trademarks are the property of their respective owners.

Open Source Code

Certain Aruba products include Open Source software code developed by third parties, including software code subject to the GNU General Public License (GPL), GNU Lesser General Public License (LGPL), or other Open Source Licenses. Includes software from Litech Systems Design. The IF-MAP client library copyright 2011 Infoblox, Inc. All rights reserved. This product includes software developed by Lars Fenneberg et al. The Open Source code used can be found at this site:

http://www.arubanetworks.com/open_source

Legal Notice

The use of Aruba Networks, Inc. switching platforms and software, by all individuals or corporations, to terminate other vendors' VPN client devices constitutes complete acceptance of liability by that individual or corporation for this action and indemnifies, in full, Aruba Networks, Inc. from any and all legal actions that might be taken against it with respect to infringement of copyright on behalf of those vendors.

Warranty

This hardware product is protected by the standard Aruba warranty of one year parts/labor. For more information, refer to the ARUBACARE SERVICE AND SUPPORT TERMS AND CONDITIONS.

Altering this device (such as painting it) voids the warranty.

© 2014 Aruba Networks, Inc. All rights reserved.



0511320-02

aruba[®]
NETWORKS

www.arubanetworks.com

1344 Crossman Avenue
Sunnyvale, California 94089

Phone: 408.227.4500
Fax 408.227.4550