

MM-FT Module Kit

This document describes how to remove and install a fan module (MM-FT) in the Mobility Master hardware appliance.

Package Contents

- MM-FT Module

Installing and Removing a Fan Module




Use standard ESD precautions when installing or removing a fan module.

The fan module is field-replaceable and hot-swappable. Hot-swapping allows you to replace the fan module without having to power down the appliance.

1. Remove the failed fan module in the Mobility Master hardware appliance.
 - a. Using a Phillips Head screwdriver, turn the screws on the fan module counter-clockwise until loose (they cannot be removed completely).
 - b. Use the fan module handle to pull the module out (see [Figure 1](#)).

Figure 1 Removing the Fan Module



2. Align the new fan module with opening in the appliance.



Ensure that the fan module is correctly aligned with the opening on the appliance. Failure to do so can result in damage to the fan module.

3. Insert the fan module into the appliance.
4. Turn the screws on the fan module clockwise until tight to secure the fan module into the appliance.

The fan module is replaced in the Mobility Master hardware appliance.

Contacting Support

Table 1 Contact Information

Main Site	www.arubanetworks.com
Support Site	https://support.arubanetworks.com
Airheads Social Forums and Knowledge Base	community.arubanetworks.com
North American Telephone	1-800-943-4526 (Toll Free) 1-408-754-1200
International Telephones	http://www.arubanetworks.com/support-services/contact-support/
Software Licensing Site	https://hpe.com/networking/support
End of Support information	http://www.arubanetworks.com/support-services/end-of-life-products/end-of-life-policy/

Table 1 Contact Information

Security Incident Response Team (SIRT)	Site: http://www.arubanetworks.com/support-services/security-bulletins/ Email: sirt@arubanetworks.com
--	--

MM-FT Module Kit Installation Guide

aruba
a Hewlett Packard
Enterprise company